



The Gas System

Your gas bottle must be turned off when travelling. To activate the gas on arrival, ensure the gas bottle is connected, the valve is open and the yellow toggle in line with the hose line. The gas bottle must be secured in place with the blue strap. The gas bottle must be returned full. Keep your gas receipt. It must be handed in with the caravan. A simple test to ensure the gas is working is to ignite one of the hobs on the oven. They will need the gas system to heat your hot water, and caravan, and operate your fridge if you are “off grid”.



Operating your Oven and Hob

Your oven and hobs operate on gas. Ensure the gas bottle is connected and turned on. You must ensure you lift the bench insert and the glass top before turning on your gas hob. Your gas oven has a safety cut-out feature and will turn off if there is excessive draft.



To start the hobs or oven, rotate the flame setting button to maximum, and simultaneously depress this button and the gas ignitor button. You will hear a clicking sound as the ignitor attempts to light. It might take a couple of attempts if there is no gas in the line.



Gas System

